

# Disconnect/Safety Switch Requirements

Safety for our technicians and customers remains a top priority for Southeast Elevator. We have adopted a new policy which is in line with the Florida Building Code. We are now requiring this type of Disconnect/Safety Switch on all 220v power supplies.

## What is it?

This will allow for a proper disconnecting means for shutting off the elevator main power (220v)

## Why?

This style disconnect and auxiliary contact is required for elevators with battery lowering, which is a standard feature for hydraulic elevators.

## Where can you buy it?

The disconnect and auxiliary switch can be purchased at most electrical supply stores.

## 220V DISCONNECT FOR ELEVATOR MAIN POWER

## 110V, 15 AMP DISCONNECT FOR ELEVATOR LIGHTS

