


Overhead Drum Electrical Requirements

NOTE: Access must be provided to a motor located at the top of the shaft



NOTE: The elevator controller can be located at the top of the shaft with the motor, but it is recommended to put it in a more accessible location for the convenience of future homeowners. Fees apply for remote locations based on the distance from the shaft.

